

M8 Application Guide (inch) • Speed & Feed

ISO Classification	EM Dia.	Type of Cut	Axial DOC	Radial DOC	Speed (SFM)	RMP	IPT	IPM
S	1/4	Rough	1.25 x D	.2 x D	80	1222	0.00080	5.87
		Slot	0.165		80	1222	0.00050	3.67
	5/16	Rough	1.25 x D	.2 x D	80	978	0.00100	5.87
		Slot	0.205		80	978	0.00063	3.67
	3/8	Rough	1.25 x D	.2 x D	80	815	0.00120	5.87
		Slot	0.250		80	815	0.00075	3.67
	1/2	Rough	1.25 x D	.2 x D	80	611	0.00160	5.87
		Slot	0.330		80	611	0.00100	3.67
	5/8	Rough	1.25 x D	.2 x D	80	489	0.00200	5.87
		Slot	0.415		80	489	0.00125	3.67
	3/4	Rough	1.25 x D	.2 x D	80	407	0.00240	5.87
		Slot	0.500		80	407	0.00150	3.67
	1	Rough	1.25 x D	.2 x D	80	306	0.00320	5.87
		Slot	0.665		80	306	0.00200	3.67

D = Tool diameter For applications in Titanium Alloys, please see our M5 series.

Common Machining Formulas

$$\text{RPM} = \frac{\text{SFM} \times 3.82}{D}$$

$$\text{SFM} = \text{RPM} \times D \times .262$$


$$\text{IPM} = \text{RPM} \times \text{IPT} \times Z$$

$$\text{MRR} = \text{RDOC} \times \text{ADOC} \times \text{IPM}$$


D Tool Cutting Diameter
R Tool Radius
Z Number of Flutes
RPM Revolutions per Minute
SFM Surface Feet per Minute
IPM Inches per Minute
MRR Metal Removal Rate
RDOC Radial Depth of Cut
ADOC Axial Depth of Cut

Radial Chip Thinning Adjustment
$$\text{IPT}_{\text{adj}} = \frac{\text{IPT} \times (D/2)}{\sqrt{(D \times \text{RDOC}) - \text{RDOC}^2}}$$

Adjustments



1. Apply chip thinning adjustment when RDOC < D



2. Ramp entry into work piece

- Ramp at 1.5°–2.5° angle
- Reduce chipload by 20% of recommended slotting rate